

Installation of ZPN 722577

RSD Frame support kit for 1989 thru 1999 Softail frames and aftermarket Softail style frames

NOTE: *Fits TPD-RSD transmissions only.*

**Contents of the kit: 1 pcs. 2-hole block, bare metal
1 pcs. single hole plate, bare metal**

**Bolt the 2-hole block on the swing arm side to the trapdoor
Install transmission, primary and engine in the frame and make sure driveline is correctly aligned.
Install the plate on the frame using the pivot bolt. The plate will get into contact with the 2-hole block. Now weld plate on block.**